

GEBRAUCHSANWEISUNG

- ① ■ Stativschraubbefestigung
Zur Stabilisierung sollte das Teleskop auf ein Stativ montiert werden.
- ② ■ Zoomring (Modell 20-60x60)
Zoomring auf Position 20x einstellen.
- ③ ■ Objektivring
Teleskop auf das zu beobachtende Objekt ausrichten.
Objektivring drehen, bis das Bild scharf ist.
Modell 20-60x60: Zoomring auf die gewünschte Einstellung drehen. Bildschärfe bei Bedarf feineinstellen.

VORSICHT: Der Blick durch das Teleskop in die Sonne kann zu Erblindung oder zu schweren und irreparablen Augenschäden führen.

PFLEGE UND LAGERUNG

Teleskop nach dem Einsatz mit aufgesetzten Schutzkappen trocken lagern. Linsen nicht berühren.


SÄUBERUNG

Staub oder Partikel wegblasen oder mit einer sanften Linsenbürste entfernen. Zur Entfernung von Schmutz oder Fingerabdrücken ein sanftes Baumwolltuch nehmen und kreisförmig von der Mitte aus über die Linse reiben. Ein rauhes Tuch oder ein übermäßiges Reiben kann Kratzer auf der Linse verursachen und unter Umständen irreparable Schäden hervorrufen.

Für eine gründlichere Reinigung kann Kameralinsenreinigungsflüssigkeit verwendet werden. Flüssigkeit niemals direkt auf die Linse auftragen, sondern erst das Putztuch damit tränken.

PRISMATIC SPOTTING SCOPE

- GB INSTRUCTIONS**
- NL HANDLEIDING**
- F MODED' EMPLOI**
- D GEBRAUCHSANWEISUNG**



INSTRUCTIONS

- ① ■ Tripod screw attachment
For stable viewing it is recommended to mount the Spotting scope on a tripod.
- ② ■ Zoom ring (model 20-60x60)
Turn zoom ring to 20x position.
- ③ ■ Focusing ring
Align spotting scope with object to be viewed.
Rotate focusing ring till a clear picture is obtained.
Model 20-60x60: Rotate zoom ring to the desired power setting. Refine focus as needed.

WARNING: Viewing the sun with this instrument can result in blindness or other serious eye damage which may be permanent.

CARE AND STORAGE

When not in use, store your spotting scope with the protective caps on in a moisture free environment. Avoid touching the lenses with your fingers.

CLEANING

Blow away any dust or debris on the lenses or use a soft lens brush. To remove dirt or fingerprints, clean with a soft cotton cloth rubbing in a circular motion from center outward. Use of a coarse cloth or unnecessary rubbing may scratch the lens surface and eventually cause permanent damage.

For a more thorough cleaning photographic-type lens cleaning fluid may be used. Always apply the fluid to the cleaning cloth: never directly to the lens.